Belle-Aqua™

1 Litre stainless steel kettle

Instruction Booklet

KE7110

Please read these instructions carefully
and retain for future reference.

Contents

Sunbeam's Safety Precautions	**1**
Features of your Sunbeam Belle-Aqua™ Kettle	**2**
Using your Sunbeam Belle-Aqua™ Kettle	**4**
Sunbeam's 3-Way Safety System	**5**
Care and Cleaning of your Sunbeam Belle-Aqua™ Kettle	**6**

Important instructions – retain for future use.

تأكد من تفهّم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich, dass die obenstehenden Sicherheitsmaßnahmen verstanden werden

Βεβαιώνετε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

کاری بکنید که احتیاط‌های بالا حتماً درك بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR YOUR SUNBEAM KETTLE.

- Always operate the kettle on a flat, level surface.
- Boiling water will scald. Do not leave a boiling or hot kettle near or where children may touch it.
- Do not leave the power cord near the edge of a bench top where children may touch or pull it.
- Boiling water may be ejected, if overfilled.
- Always ensure lid is securely closed to ensure correct operation of the kettle.
- Do not operate the kettle without water.
- Always turn the power off and unplug the cord while the kettle is NOT in use.
- Your kettle must only be used with the power base supplied.
- Do not move kettle while switched on.
- Never fill above the 'max' indication as hot water may be ejected.
- Always store excess cord in the storage facility underneath the power base.
- Always be aware of steam being emitted from the spout or lid especially during refilling.
- Do not use the kettle to heat anything other than water.

Sunbeam is very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:

- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- Close supervision is necessary when your appliance is being used by children or infirm persons.
- Young children should be supervised to ensure that they do not play with the appliance.
- Never leave an appliance unattended while in use.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven. Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.
- Appliances are not intended to be operated by means of an external timer or separate remote control system.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line

Ensure the above safety precautions are understood.

Features of your Sunbeam Belle-Aqua™ Kettle

Large spout
Enables quick and easy filling at the tap, without the need for removal of the lid.

Removable mesh filter
Keeps the water clean of any foreign matter and is removable or easy cleaning.

1850 watt concealed element
The fast boil 1850 watt element is concealed in the base of the kettle for longer element life. The smooth stainless floor reduces scale build up and allows for easy cleaning.

360 degree cordless power base
Designed to allow you to place the kettle on the base in any direction.



3-Way Safety System.

1 – Automatically switches the kettle off after boiling.

2 – Cuts out for boil-dry production.

3 – Shuts down in case of overheating.



Lid release button

Simply pull the lid release button to open the lid.

Neon ON/OFF switch with auto cut-out on handle

Lights up to indicate that the kettle is on and heating. Switches the kettle off automatically after boiling.

Stylish brushed stainless steel design

Long life stainless steel to suit any kitchen décor.

Cord storage facility

Excess cord can be wound around the cord storage facility underneath the power base.

Using your Sunbeam Belle-Aqua™ Kettle

Before using your kettle.

It is recommended that you clean your kettle before first use by filling the kettle with water, up to the maximum level indicator, boil and discard.

Using your kettle.

1. To fill the kettle, remove it from the power base and open the lid by pushing the button on the top of the lid. Alternatively, the kettle may be filled through the pouring spout.
2. Fill the kettle with the desired amount of water (minimum 1 cup/250ml). Always fill the kettle between the minimum and maximum marks. Too little water will result in the kettle switching off before the water has boiled.

Note: Do not fill the kettle over the maximum level, as water may spill out of the spout when boiling.

3. Push the lid closed firmly until it locks into position.
4. Place the kettle on the power base and connect the plug into a 230/240 Volt AC power outlet. Turn the power ON.
5. Press the ON/OFF switch located on the handle downwards. The light will illuminate to indicate the kettle is heating.

The kettle will switch off automatically once the water has boiled.

Important: Ensure the lid is firmly closed. The kettle will not turn off if the lid is left open. Do not remove the kettle from the power base while in use.

Important: Avoid touching metal surfaces when operating the kettle as these will be hot.

6. Lift the kettle from the power base and pour the water.

Note: Use caution when pouring the water from your kettle as boiling water will scald.

7. The kettle may be stored on the power base while not in use. The kettle will not re-boil until the ON/OFF switch is pressed downward.

Note: Ensure the power is turned off at the power outlet when the kettle is not in use.

Should you accidentally allow the kettle to operate without water, it will cut out for boil-dry protection. If this occurs, allow the kettle to cool before filling with cold water and re-boiling.

Cord Storage Facility.

Excess cord can be stored by winding the cord around the storage facility underneath the power base.



360° power base

Sunbeam's 3-Way Safety System

Safety is a major consideration in the design of a Sunbeam kettle. This is why we have developed our 3-Way Safety System, which ensures that your kettle will:

1. **Automatically switch off after boiling.**
   For convenience, safety and energy efficiency, your Sunbeam kettle features an auto cut-out device.

2. **Cut-out for boil-dry protection.**
   If the kettle is operated without water, it will automatically cut-out, preventing any damage to the element.

3. **Shut-down in case of overheating.**
   In the event of overheating, the kettle will automatically shut down to prevent further damage. Should this occur, take your kettle to a Sunbeam Service Centre or Appointed Service Agent.

Care and Cleaning

Always disconnect the kettle from the power outlet before cleaning.

Never immerse the kettle switch area, cord or power base in water, or allow moisture to come into contact with these parts.

Removal of mineral deposits.

Mineral deposits in tap water may cause the interior of the water gauge to discolour. To remove this build-up, use Sunbeam Liquid Descaler, a simple to use, non-toxic cleaner available from Sunbeam Appointed Service Agents.

Alternatively:

1. Fill the kettle with 3 cups of white vinegar and the remainder with water and allow to stand overnight. DO NOT BOIL.
2. Empty the solution from the kettle. Fill the kettle with clean water, bring to boil and then discard the water. Repeat and the kettle will then be ready to use.

To clean the stainless exterior.

The stainless steel surface may be wiped over with a damp cloth and polished with a soft dry cloth.

CAUTION: Do not use chemical, steel wool, or abrasive cleaners to clean the outside of the kettle, as these will scratch the stainless steel surface.

To clean the mesh filter.

Press the button on the top of the lid to open the lid. Grasp the top of the scale filter and pull upwards to remove. Wash in warm soapy water and dry thoroughly before replacing in the kettle.

Notes

Notes

12 Month Replacement Guarantee

In the unlikely event that this appliance develops any malfunction within 12 months of purchase (3 months commercial use) due to faulty materials or manufacture, we will replace it for you free of charge.

Should you experience any difficulties with your appliance, please phone our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand.

Your Sunbeam 12 Month Replacement Guarantee naturally does not cover misuse or negligent handling, and excludes breakables such as glass or ceramic items and normal wear and tear.

Similarly, your 12 Month Replacement Guarantee does not cover damage to household surfaces as a result of water or other substances leaking from your appliance, nor does it cover freight costs.

In Australia, this guarantee is additional to the conditions and guarantees which are mandatory as implied under the Trade Practices Act 1974 and State and Territory legislation.

Should your appliance require repair or service after the guarantee period, contact your nearest Sunbeam service centre.

For a complete list of Sunbeam's authorised service centres visit our website or call:

Australia

www.sunbeam.com.au

1300 881 861

New Zealand

www.sunbeam.co.nz

0800 786 232

Need help with your appliance?

Contact our customer service team or visit our website for information and tips on getting the most from your appliance.

In Australia

Visit www.sunbeam.com.au

Or call 1300 881 861

In New Zealand

Visit www.sunbeam.co.nz

Or call 0800 786 232

Sunbeam is a registered trademark.

Made in China.
Due to minor changes in design or otherwise, the product may differ from the one shown in this leaflet.

© Copyright. Sunbeam Corporation Limited 2010.

ABN 45 000 006 771
Sunbeam Corporation is a division of GUD Holdings Ltd.

6/10